CABINET PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)

29" Electric Dryer



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8535829	Installation Instructions
	LIT8533771	Sheet, Cycle Feature
	LIT8522243	Use & Care Guide
	LIT8533775	Tech Sheet
	LIT8535825	Sheet, Feature Resource Saver
Following May Be Purchased		
DO−IT−YOURSELF REPAIR MANUALS		
	LIT677818	Dryer
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, 8−18 x 3/8
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	342043	Screw, 10−32 x 3/8
7	3396805	Panel, Rear
8	8546676	Clip, Door Spring
9	98669	Locator, Top
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	18849	Pad, Top Hinge
13	3357011	Screw, 10−16 x 1/2
14	8541401	Spring, Door (2)
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 34)
18		Cabinet (Includes Illus. 4)
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground
20	18776	Lock, Front Top (2)
21		Panel, Front
	695620	White
	3977244	Biscuit
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	696144	Strike, Door
30	695737	Door, Rear
31		Door, Front
	3393549	White
	3977241	Biscuit
32		Handle, Door
	690270	White
	3977242	Biscuit
33	3406129	Seal & Bearing Assembly
34	279393	Terminal Block Kit (For Terminal Block)
35	697776	Screw, 10−32 x 5/8
36	3397659	Block, Terminal
37	238088	Hinge, Top (2)
38	691366	Idler & Pulley Assembly
39	8066065	Belt, Drive
40	348780	Base, Motor
41	3400500	Bolt, 5/16−18 x 3/4
42	3394341	Pulley, 60 Hz.
43	8538262	Motor Assembly 60 Hz.
44	660658	Clamp, Motor
45	3404162	Clamp, Motor (W/Shield)
46	3390731	Seal, Door
47	3393008	Screw, 10−16 x 1/2

TOP AND CONSOLE PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)



WIRING HARNESS PARTS

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console
2	8283135	Harness, Console
3	693995	Screw, Hex Head
4		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
5	3405151	Switch, Signal
6	388326	Screw, Console
7		Knob, Push−To−Start
	8544941	Silver
	8544942	Biscuit
8		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
9	3405152	Switch, Wrinkle Shield
10		Screen, Lint
	8557857	White
	8557858	Biscuit
11	8536939	Clip, Spring
12	237446	Washer (Top/Chute)
13	688983	Screw, 8−18 x 5/8
14	3400859	Screw, Grounding
15	3395683	Connector (Motor)
16		Top
	8557927	White
	8557928	Biscuit
17		Knob, Control (3)
	8544937	Silver
	8544938	Biscuit
18	3394427	Clip−Harness
20	8533990	Medallion
21	8299771	Timer, 60 Hz.
22	8299970	Switch, Temperature
23	3405281	Power Relay (2)
24	3976623	Control Board
25	3390646	Screw, Mounting (8−18 x 5/16)
26	357213	Nut, Push−In (2)
27	8299897	Harness, Wiring
28	3397269	Connector (Timer)
29	3347243	Connector 6−Circuit
30	94614	Terminal
31	3977456	Switch, Push−To−Start
32		Timer Knob Assembly
	8544957	Silver
	8544958	Biscuit
33	3936144	Connector
34	8544895	Bracket, Control
35		Panel, Control (Includes Illus. 20)
	8545982	Silver
	8545984	Gold
36	343641	Screw, 10−16 x 1/2
37	697812	Heat Relay
38	3388228	Screw, 6−20 x 3/8
39	3936150	Connector, 7−Circuit

BULKHEAD PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GEW9878PW0, GEW9878PG0
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8−15 x 1/2
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	696302	Shield, Exhaust
7	3390719	Thermal Fuse
8	3976615	Thermistor
9	3977393	Thermal, Cut−Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	8557385	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3404153	Thermostat, 180°F (82.2°C)
16	3977373	Bracket, Drum Light
17	3401338	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8−18 x 5/8
21	3390647	Screw, 8−18 x 1/2
22	3394196	Seal, Blower
23	3976479	Pad, Sensor
24	3406124	Bulb
25	3402841	Lens, Drum Light
26	690997	Ring, Tri
27	3399506	Shaft, L.H.
28	3399507	Shaft, R.H.
29	3397588	Roller, Support
30	348197	Washer, Support
31	3359452	Nut, 3/8−16
32	3403414	Bulkhead
33	3403634	Socket Assembly
34	692526	Ring, Bearing (2)
35	97787	Screw, 11−16 x 3/4
36	3406130	Seal, Rear Drum
37	695587	Drum Assembly
38	692490	Baffle, Drum (2)
39	3976434	Bracket, Support
40	90296	Clip
41	3403636	Baffle, Drum (1)
42	339956	Seal

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit(Uncut)